



### Electrical functions

The wheelchair is awakened from "sleep" by pressing a random button on the controller.

### The controller

The battery indicator is shown at the top of the remote control. Charge the wheelchair when the battery reaches the red box.

The wheelchair is charged when the cable in the control box is connected to power. A full charge takes up to six hours. Please charge the wheelchair when receiving it.

The recline function is located under the battery indicator. The arrows activate the recline function (from 96°- 131°).

The recline function is locked for safety reasons. To use it, hold down "Recline up" and "Tilt down" for 10 seconds.

A beep will confirm that the function can be used. After 30 seconds of inactivity, the function locks again.

Under the recline function is the tilt function. The seat on Kamille Comfort Wheelchair can be tilted from 0° to 45°.

Always use the tilt and recline functions carefully to avoid quick jerks.

Kamille Comfort Wheelchair has two actuators; one seat actuator and a back actuator.

If the actuators stop functioning, the remote control must be RESET. Make sure that both actuators run during RESET.

### Brakes

The brake levers are mounted on the push bar. The levers are equipped with a lock that can be unlocked by holding the brake lever in while pressing the red release button.

### Daily maintenance

Clean the frame, seat and arm rests of the wheelchair using water and a regular cleaning agent.

The cushions can be removed and disinfected using ethanol 70-85% or a chlorine product of min. 1000 ppm and max. 10000 ppm.

The remote control can be disinfected with the same products as the cushions.



### RESET - controller

Press and hold down the two arrows, marked with a red dot, for 5 seconds.

It causes the two actuators to reach "zero-position".

When RESET is completed, the electrical functions work again.

## QUICK GUIDE

# Kamille Comfort Wheelchair

## Guide til transfer, electrical functions, and charging.

### From bed to wheelchair active user

1. Swing footrests to the sides.
2. Adjust the seat angle to the needs of the user.
3. User sits down in the wheelchair.
4. Adjust the hip angle via the controller.
5. Swing back the footrests.

### From bed to wheelchair - dependent user.

1. Swing footrests to the sides.
2. Adjust the seat angle to the needs of the user.
3. Adjust the hip angle via the controller.
4. Tilt the wheelchair backwards.
5. Swing back one arm rest.
6. Lift user sideways into the chair.
7. Swing back footrests and arm rest.

### Adjusting the wheelchair

Make sure to assess the need of extra or less filling in the different cushions when user is placed in the wheelchair.

The angle of the push bar can be adjusted using the two thumb screws located on the right and left sides of the push bar.

The height of the push bar can be adjusted using the hand levers located on the back.

Armrests can be adjusted in height and angle using the thumbscrews on the sides.

Leg rests are adjustable in both height and position. They also have a swing away function.

The angle of the foot plate, the angle of the leg rest and the angle of the calf plate can be adjusted with tools.

Scan the code and get more information on Kamille Comfort Wheelchair.

